



IoT Inertial Measurement Unit Monitoring

จัดทำโดย

นายธนวิทย์ ศิริวรรณ 6203014610060

เสนอ

ผู้ช่วยศาสตราจารย์ ดร.สุพจน์ แก้ววรรณ

รายงานเล่มนี้เป็นส่วนหนึ่งของวิชาการโปรแกรมคอมพิวเตอร์สำหรับงานควบคุม

สาขาวิชาเทคโนโลยีวิศวกรรมแมคคาทรอนิกส์

ภาควิชาเทคโนโลยีวิศวกรรมเครื่องกล

วิทยาลัยเทคโนโลยีอุตสาหกรรม

มหาวิทยาลัยเทคโนโลยีพระจอมเกล้าพระนครเหนือ

พ.ศ.2565

คำนำ

รายงานเล่มนี้เป็นส่วนหนึ่งของวิชา 030143361 Computer Programming For Control โดยจัดทำขึ้นโดยเพื่อศึกษาการเขียนโปรแกรมคอมพิวเตอร์สำหรับการควบคุมโดยใช้โปรแกรม Delphi ซึ่งรายงานเล่มนี้มีเนื้อหาเกี่ยวกับการเขียนโปรแกรมติดต่อรับส่งข้อมูลกับคอนโทรลเลอร์แสดงผล และบันทึกผลการทำงาน

ผู้จัดทำได้ทำรายงานเล่มนี้ขึ้นเพื่อแสดงการใช้โปรแกรม Delphi ในการเขียนโปรแกรมติดต่อสื่อสาร และแสดงผล โดยใช้ Arduino และคอมพิวเตอร์ร่วมกัน ผู้จัดทำหวังว่ารายงานเล่มนี้จะมีประโยชน์แก่ผู้ที่เข้ามาศึกษาหากรายงานเล่มนี้มีข้อผิดพลาดประการใดทางผู้จัดทำขออภัยมา ณ ที่นี้ด้วย

ผู้จัดทำ

ธนวินท์ ศิริวรรณ

1. ที่มาและความสำคัญ

เพื่อพัฒนาระบบแสดงสถานะการทำงานของเซนเซอร์ GY-91 ที่เชื่อมต่อ Arduino และสื่อสารรับส่งข้อมูลกับคอมพิวเตอร์ด้วย TCP/IP โดยสามารถนำข้อมูลที่ได้จาก Arduino ที่ต่อกับเซนเซอร์ GY-91 (IMU) นำมาพล็อตกราฟ Acceleration, Gyro, Magnetometer, Temperature และบันทึกค่าไปยังฐานข้อมูล MQTT สามารถบันทึกเป็น Text ไฟล์ และสามารถแสดงสถานะการทำงานผ่าน Node-RED

2. วัตถุประสงค์

- 2.1 เพื่อศึกษาการเขียน VCL/FMX Application ด้วย Delphi
- 2.2 เพื่อศึกษาการส่งข้อมูลสื่อสารกับ Arduino ผ่าน TCP/IP ด้วย Delphi
- 2.3 เพื่อออกแบบระบบ IoT Inertia Measurement Unit Monitoring


3. ขอบเขตการทำงาน

- 3.1 สามารถรับส่งข้อมูลไปยัง Arduino ผ่าน TCP/IP
- 3.2 สามารถทำการแสดงค่าสัญญาณของ GY-91
- 3.3 สามารถส่งข้อมูลไปเก็บที่ฐานข้อมูล
- 3.4 สามารถบันทึกค่าที่อ่านจากเซนเซอร์ลง Text ไฟล์
- 3.5 สามารถควบคุมการเคลื่อนที่วัตถุ 3 มิติ
- 3.6 สามารถส่งข้อมูลไปยัง MQTT
- 3.7 สามารถทำการแสดงสถานะการทำงานของระบบด้วย Node-RED

4. ผลที่คาดว่าจะได้รับ

- 4.1 ระบบสามารถรับส่งข้อมูลกับ Arduino ผ่าน TCP/IP ได้
- 4.2 ระบบสามารถส่งบันทึกข้อมูลไปยังฐานข้อมูลได้
- 4.3 ระบบสามารถส่งบันทึกข้อมูลในรูปแบบ Text ไฟล์ได้
- 4.4 ระบบสามารถรับส่งข้อมูลกับ MQTT ได้

5. Block Diagram แสดงขั้นตอนการทำงาน



6. การเชื่อมต่อ


- 6.1 Arduino เชื่อมต่อกับโมดูล GY-19 ด้วย I2C
- 6.2 Arduino เชื่อมต่อ Arduino Ethernet Shield ด้วย SPI
- 6.3 คอมพิวเตอร์สื่อสารกับ Arduino ผ่าน TCP/IP โดย Arduino จะเป็น Server และคอมพิวเตอร์เป็น Client

7. การดำเนินงาน


- 7.1 ออกแบบระบบ
- 7.2 การเขียนโปรแกรมให้ Arduino อ่านค่าจาก GY-91
- 7.3 การเขียนโปรแกรมให้ Arduino เชื่อมต่อกับอินเทอร์เน็ต
- 7.4 การเขียนโปรแกรม Delphi สื่อสารกับ Arduino ผ่าน TCP/IP
- 7.5 การเขียนโปรแกรม Delphi ส่งข้อมูลไปยังฐานข้อมูล
- 7.6 การเขียนโปรแกรม Delphi ส่งและรับข้อมูลจาก MQTT
- 7.7 การเขียนโปรแกรมบันทึกค่าจาก GY-91 ลง text ไฟล์
- 7.8 การเขียนโปรแกรมควบคุมวัตถุ 3 มิติ
- 7.9 การเขียนโปรแกรม Delphi พล็อตกราฟ
- 7.10 การเขียนโปรแกรม Node-RED รับค่าจาก MQTT

8. การออกแบบ Interface


8.1 หน้าหลัก




8.2 การพล็อตกราฟ Acceleration X, Y, Z




8.3 การพล็อตกราฟ Acceleration Norm




8.4 การพล็อตกราฟ Gyro X,Y,Z




8.5 การพล็อตกราฟ Magnetometer X,Y,Z Axis



8.6 การพล็อตกราฟ Magnetometer Horizontal



8.7 การพล็อตกราฟ Temperature and pressure



8.8 MySQL

IMU Data Monitoring by Two Tanawin

Inertial Measurement Unit

192.168.1.111

80

Connect

Disconnect

Start

Stop

SaveData

StopSave

StartSQL

StopSQL

☐ StartWithSQL

State : ?

MonitoringData

TableData

Acc_Data

Acc_Sqrt

Gyro_Data

Meg_Data

MegDirection

Temp_Press

RawData

MqttData

WedNoedRed

TabItem3

DateTime	acceleratio...	acceleratio...	acceleratio...	accelerationNor...	GyroX	GyroY	GyroZ	MagnetoX	MagnetoY	MagnetoZ	magHorizDirecti...	Temperatu...	Pre
11/21/2022 10:24:0...	-0.31	-0.1	0.99	1.04	0.31	0.79	1.83	-86.53	6.11	-139.45	-85.96	31.22	
11/21/2022 10:24:0...	-0.31	-0.09	0.99	1.04	-0.85	0.06	3.42	-84.09	1.22	-141.8	-89.17	31.24	
11/21/2022 10:24:1...	-0.3	-0.1	0.99	1.04	0.73	1.28	0.67	-86.53	2.45	-138.28	-88.38	31.25	
11/21/2022 10:24:4...	0	0	0	0	0	0	0	0	0	0	0	0	
11/21/2022 10:24:5...	-0.31	-0.1	0.99	1.04	-0.98	-1.04	3.05	-85.31	6.11	-138.28	-85.9	31.23	
11/21/2022 10:25:0...	-0.3	-0.1	0.99	1.04	1.71	1.89	-0.37	-85.31	4.89	-139.45	-86.72	31.23	
11/21/2022 10:25:1...	-0.3	-0.1	0.98	1.03	-0.67	0.73	2.87	-85.31	3.67	-138.28	-87.54	31.25	
11/21/2022 10:25:3...	-0.31	-0.1	0.98	1.04	0.18	0.18	1.83	-85.31	2.45	-141.8	-88.36	31.25	
11/21/2022 10:25:4...	-0.31	-0.1	0.98	1.04	3.36	3.23	-0.37	-85.31	3.67	-139.45	-87.54	31.26	
11/21/2022 10:25:4...	-0.31	-0.1	0.98	1.03	-1.1	-0.79	3.48	-85.31	4.89	-140.63	-86.72	31.25	
11/21/2022 10:25:5...	-0.31	-0.1	0.98	1.03	-1.1	-0.79	3.48	-85.31	4.89	-140.63	-86.72	31.25	
11/21/2022 10:25:5...	-0.31	-0.1	0.98	1.03	-1.1	-0.79	3.48	-85.31	4.89	-140.63	-86.72	31.25	
11/21/2022 10:26:3...	-0.31	-0.09	0.98	1.03	2.99	3.72	0.37	-86.53	4.89	-139.45	-86.77	31.24	
11/21/2022 10:26:4...	-0.31	-0.09	0.99	1.04	0.61	1.46	2.2	-84.09	3.67	-141.8	-87.5	31.25	
11/21/2022 10:27:5...	-0.3	-0.1	0.98	1.03	-0.61	0	1.53	-87.75	2.45	-141.8	-88.4	31.25	
11/21/2022 10:32:5...	-0.24	-0.17	0.99	1.04	4.03	5.07	-2.26	-88.97	12.23	-133.59	-82.18	31.29	
11/21/2022 10:33:0...	-0.24	-0.18	1	1.04	-0.31	0.06	3.05	-88.97	11	-133.59	-82.95	31.3	
11/21/2022 11:29:4...	-0.08	-0.22	0.91	0.94	5.98	33.14	13.79	-78	18.34	-145.31	-76.77	32.64	
11/21/2022 11:29:5...	0.36	-0.64	0.7	1.01	-2.32	-6.53	0.73	-71.91	14.67	-86.72	-78.47	32.58	
11/21/2022 11:29:5...	-0.42	-0.29	0.91	1.04	0.92	1.28	0.98	-91.41	-7.34	-130.08	-94.59	32.54	

8.9 Raw Data

IMU Data Monitoring by Two Tanawin

Inertial Measurement Unit: 192.168.1.111
80

Connect Start SaveData StopSave StartSQL ☐ StartWithSQL
Disconnect Stop State : ?

MonitoringData TableData Acc_Data Acc_Sqrt Gyro_Data Meg_Data MegDirection Temp_Press **RawData** MqttData WedNoedRed TabItem3

Raw IMU Data



8.10 MQTT

IMU Data Monitoring by Two Tanawin

Inertial Measurement Unit: 192.168.1.111
80

Connect Start SaveData StopSave StartSQL ☐ StartWithSQL
Disconnect Stop State : ?

MonitoringData TableData Acc_Data Acc_Sqrt Gyro_Data Meg_Data MegDirection Temp_Press RawData **MqttData** WedNoedRed TabItem3

Publcer And Subscriber MQTT



Connect

9. โปรแกรม Delphi

unit Main;

interface

uses

System.SysUtils, System.Types, System.UITypes, System.Classes, System.Variants,
FMX.Types, FMX.Controls, FMX.Forms, FMX.Graphics, FMX.Dialogs, FMX.Edit,
FMX.Controls.Presentation, FMX.StdCtrls, IdBaseComponent, IdComponent,
IdTCPConnection, IdTCPClient, FMX.Memo.Types, FMX.ScrollBox, FMX.Memo,
FMX.TabControl, FMX.Tee.Engine, FMX.Tee.Procs, FMX.Tee.Chart,
System.Math.Vectors, FMX.Types3D, FMX.Objects3D, FMX.Controls3D,
FMX.Viewport3D, FMX.Tee.Series, FireDAC.Phys.FBDef, FireDAC.Stan.Intf,
FireDAC.Stan.Option, FireDAC.Stan.Error, FireDAC.UI.Intf, FireDAC.Phys.Intf,
FireDAC.Stan.Def, FireDAC.Stan.Pool, FireDAC.Stan.Async, FireDAC.Phys,
FireDAC.FMXUI.Wait, FireDAC.Stan.Param, FireDAC.DatS, FireDAC.DApt.Intf,
FireDAC.DApt, Data.DB, FireDAC.Comp.DataSet, FireDAC.Comp.Client,
FireDAC.Phys.IBBase, FireDAC.Phys.FB, FireDAC.Phys.MySQL,
FireDAC.Phys.MySQLDef, System.Rtti, FMX.Grid.Style, FMX.Grid,
Data.Bind.EngExt, Fmx.Bind.DBEngExt, Fmx.Bind.Grid, System.Bindings.Outputs,
Fmx.Bind.Editors, Data.Bind.Components, Data.Bind.Grid, Data.Bind.DBScope,
FMX.Tee.Control, FMX.Tee.Grid, FMX.TMSBaseControl, FMX.TMSGridCell,
FMX.TMSGridOptions, FMX.TMSGridData, FMX.TMSCustomGrid, FMX.TMSGrid,
FMX.Layouts, FMX.ListBox, TMS.MQTT.Global, TMS.MQTT.Client, Math, IniFiles,
FMX.WebBrowser, FMX.TMSWebBrowser, FMX.TMSTaskDialog;

const

GRAPH_MAX_NUM = 200;

LP_K = 0.3;

HP_K = 0.01;

SAMPLING_TIME = 0.01; // 10mS.

MOVIVE_AVG_LEN = 10; // 10mS. * 100 = 1000mS.

ACC_NORM_VAL = 101;

type

TClientRead = class(TThread)

private

protected

procedure Execute; override;

end;

```
type
TModel = class(TThread)
private
protected
  procedure Execute; override;
end;
```

```
type
TMyThreadSQL = class(TThread)
private
  LastData:String;
  procedure DataToSQL(aX,aY,aZ,aN,gR,gP,gY,mgX,mgY,mgZ,mgH,temp,press,Alti:Single);
  procedure ShowDataSQL();
protected
  procedure Execute; override;
end;
```

```
type
Tmy3d = class(TThread)
  private
    procedure callSig();
  protected
    procedure Execute; override;
end;
```

```
type
TMyPlot = class(TThread)
private
protected
  procedure Execute; override;
end;
```

```
type
TrecData = class(TThread)
  private
  protected
    procedure Execute; override;
end;
```

```
type
TMoveAvg = record
```

```
    Data:Array [1..10] of Single;  
end;
```

```
type  
  TLowPass = record  
    LastLp:Single;  
    LastHp:Single;  
  end;
```

```
type  
  THighPass = record  
    LastHp:Single;  
    LastDataIn:Single;  
  end;
```

```
Type  
  tAcc = record  
    X:Single;  
    Y:Single;  
    Z:Single;  
  end;
```

```
type  
  TaccData = record  
    aX:String;  
    aY:String;  
    aZ:String;  
    rq:String;  
  end;
```

```
type  
  TgyroData = record  
    gyroX:String;  
    gyroY:String;  
    gyroZ:String;  
  end;
```

```
type  
  TmagData = record  
    magX:String;  
    magY:String;  
    magZ:String;  
    magH:String;  
  end;
```

```
type
  TtempData = record
    TempX:String;
    PressX:String;
  end;
```

```
type
  Tsignal = record
    accX:Single;
    accY:Single;
    accZ:Single;
    accNorm:Single;
    gyroR:Single;
    gyroP:Single;
    gyroY:Single;
  end;
```

```
type
  TsignalLP = record
    accX:Single;
    accY:Single;
    accZ:Single;
    accNorm:Single;
    gyroR:Single;
    gyroP:Single;
    gyroY:Single;
  end;
```

```
type
  TMydata = record
    accX:Single;
    accY:Single;
    accZ:Single;
    accNorm:Single;
    gyroR:Single;
    gyroP:Single;
    gyroY:Single;
    magX:Single;
    magY:Single;
    magZ:Single;
  end;
```

```
type
```

```
TGyro = record  
  X:Integer;  
  Y:Integer;  
  Z:Integer;  
  Norm:Single;  
end;
```

```
type  
  TEmailDetail = record  
    User, Pass, FromAddr, ToAddr, Subject, Body, Info, FilePath:String;  
  end;
```

```
type  
  TMovingAvgBuffer = record  
    Data:array[1..MOVIVE_AVG_LEN] of Integer;  
  end;
```

```
type  
  TGyroForce = record  
    FX: Single;  
    FY: Single;  
    FZ: Single;  
    Fr:Single;  
  end;
```

```
type  
  TCalData = record  
   OldData: Single;  
    NewData: Single;  
  end;
```

```
type  
  TImuAngle = record  
    AngX: TCalData;  
    AngY: TCalData;  
    AngZ: TCalData;  
  end;
```

```
type  
  TForm1 = class(TForm)  
    IdTCPClient1: TIdTCPClient;  
    Z: TPanel;  
    Edit1: TEdit;  
    Edit2: TEdit;
```

Connect: TButton;
Disconnect: TButton;
Edit3: TEdit;
Stop: TButton;
Start: TButton;
TabControl1: TTabControl;
MonitoringData: TTabItem;
TableData: TTabItem;
Acc_Data: TTabItem;
Acc_Sqrt: TTabItem;
Gyro_Data: TTabItem;
Meg_Data: TTabItem;
MegDirection: TTabItem;
Temp_Press: TTabItem;
RawData: TTabItem;
Memo1: TMemo;
Chart1: TChart;
Chart2: TChart;
Chart3: TChart;
Chart4: TChart;
Chart5: TChart;
Chart6: TChart;
AccX: TLineSeries;
GyroX: TLineSeries;
AccY: TLineSeries;
GyroY: TLineSeries;
AccZ: TLineSeries;
GyroZ: TLineSeries;
Viewport3D1: TViewport3D;
Camera1: TCamera;
Light1: TLight;
Model3D1: TModel3D;
FDPhysFBDriverLink1: TFDPhysFBDriverLink;
FDConnection1: TFDConnection;
FDTable1: TFDTable;
DataSource1: TDataSource;
FDTable1DateTime: TDateTimeField;
FDTable1accelerationX: TSingleField;
FDTable1accelerationY: TSingleField;
FDTable1accelerationZ: TSingleField;
FDTable1accelerationNorm: TSingleField;
FDTable1GyroX: TSingleField;
FDTable1GyroY: TSingleField;
FDTable1GyroZ: TSingleField;

FDTable1MagnetoX: TSingleField;
FDTable1MagnetoY: TSingleField;
FDTable1MagnetoZ: TSingleField;
FDTable1magHorizDirection: TSingleField;
FDTable1Temperature: TSingleField;
FDTable1Pressure: TSingleField;
FDTable1Altitude: TSingleField;
BindSourceDB1: TBindSourceDB;
BindingsList1: TBindingsList;
StringGrid1: TStringGrid;
LinkGridToDataSourceBindSourceDB12: TLinkGridToDataSource;
Chart7: TChart;
Chart8: TChart;
Chart9: TChart;
AccXD: TLineSeries;
AccYD: TLineSeries;
AccZD: TLineSeries;
Chart10: TChart;
Chart11: TChart;
Chart12: TChart;
Chart13: TChart;
Chart14: TChart;
AccSQRTD: TLineSeries;
GyroXD: TLineSeries;
GyroYD: TLineSeries;
GyroZD: TLineSeries;
Chart15: TChart;
Chart16: TChart;
Chart17: TChart;
Chart18: TChart;
Chart19: TChart;
magX: TLineSeries;
MagY: TLineSeries;
MagZ: TLineSeries;
MagH: TLineSeries;
TempS: TLineSeries;
PressS: TLineSeries;
Timer1: TTimer;
MqttData: TTabItem;
TMSMQTTClient1: TTMSMQTTClient;
SaveData: TButton;
WedNoedRed: TTabItem;
Label1: TLabel;
ListBox1: TListBox;


```

Memo2: TMemo;
TabItem3: TTabItem;
EditWeb: TEdit;
TMSFMXWebBrowser1: TTMSFMXWebBrowser;
ReFresh: TButton;
StopSave: TButton;
StopSQL: TButton;
TMSFMXTaskDialog1: TTMSFMXTaskDialog;
CheckBox1: TCheckBox;
Button1: TButton;
StartSQL: TButton;
SQLStat: TLabel;
Label2: TLabel;
Label3: TLabel;
Label4: TLabel;
procedure ConnectClick(Sender: TObject);
procedure DisconnectClick(Sender: TObject);
procedure FormCreate(Sender: TObject);
procedure TestClick(Sender: TObject);
procedure StopClick(Sender: TObject);
procedure StartClick(Sender: TObject);
procedure FormClose(Sender: TObject; var Action: TCloseAction);
procedure Timer1Timer(Sender: TObject);
procedure TMSMQTTClient1ConnectedStatusChanged(ASender: TObject;
  const AConnected: Boolean; AStatus: TTMSMQTTConnectionStatus);
procedure TMSMQTTClient1PublishReceived(ASender: TObject; APacketID: Word;
  ATopic: string; APayload: TArray<System.Byte>);
procedure SaveDataClick(Sender: TObject);
procedure FormKeyDown(Sender: TObject; var Key: Word; var KeyChar: Char;
  Shift: TShiftState);
procedure ReFreshClick(Sender: TObject);
procedure IdTCPClient1Connected(Sender: TObject);
procedure IdTCPClient1Disconnected(Sender: TObject);
procedure StopSaveClick(Sender: TObject);
procedure StartSQLClick(Sender: TObject);
procedure StopSQLClick(Sender: TObject);
procedure FormDestroy(Sender: TObject);
procedure CheckBox1Change(Sender: TObject);
procedure IdTCPClient1Status(ASender: TObject; const AStatus: TIdStatus;
  const AStatusText: string);
private
{ Private declarations }
accData:TaccData;
gyroData:TgyroData;

```

```
magData:TmagData;
MoveAvg:TMoveAvg;
LowPass:TLowPass;
HighPass:THighPass;
tempData:TtempData;
Accel:TAcc;
Signal:Tsignal;
signalLP:TsignalLP;
MyData:TMyData;
MyDataFile:TextFile;
MyDataPath:String;
myEmailDetail:TEmailDetail;
MyCleint:TClientRead;
MyModel:TModel;
ThreadSQL:TMYThreadSQL;
ThreadGrid:TGrid;
ThreadPlot:TMyPlot;
MyImu:array[1..100] of TMydata;
MyRec:TrecData;
My3d:TMy3d;
GyroAng:TImuAngle;
iniFilePath:String;
procedure ReadIniCfg();
procedure WriteIniCfg();
procedure CreateCleint();
procedure PreModel();
procedure PlotAcc();
procedure PlotGyro();
procedure PlotAccD();
procedure PlotGyroD();
procedure PlotNorm();
procedure PlotMag();
procedure PlotMagH();
procedure Teamp_Press();
procedure SumPlot();
procedure PlotLineGraph(Graph: TLineSeries; Data:Real);
procedure SetZero();
procedure startGrid();
procedure DataToSQL(aX,aY,aZ,aN,gR,gP,gY,mgX,mgY,mgZ,mgH,temp,press,Alti:Single);
procedure ShowDataSQL();
procedure ThreadSqlStart();
procedure EndThreadSQL();
procedure Thread3dStart();
procedure EndThread3d();
```

```

procedure ThreadPlotStart();
procedure EndThreadPlot();
procedure AddMessage(AMessage: string; AlignRight: boolean);
procedure RunMqtt();
procedure CallMqtt();
procedure recMyData();
procedure recDataStart();
procedure recDataStop();
function FloatToStr2(Data: Single): String;
procedure StartClient();
procedure StopClient();
procedure ThreadModelStop();

//-----Cal Data-----//
function LpFilter(k, OldVal, InputVal:Single):Single;
function HpFilter(k, OldVal, InputVal:Single):Single;
function CalMovingAvg(DataIn:Integer; var DataBuff:TMovingAvgBuffer):Integer;

function CallGyroForce(NewData:TGyro):TGyroForce;
function ChkNoMove(OldVal, NewVal:Integer):Boolean;
function ChkNoMove2(AccNorm:Single):Boolean;
procedure AddLog(AMessage: string);
procedure callini();
procedure reCheck();
public
{ Public declarations }
end;

var
Form1: TForm1;
lastData:String;
ImuData:String;
Norm:String;
AccNoMoveCount:Integer;

implementation

const
ChatChannel = 'sensor1';

{$R *.fmx}

procedure TForm1.Teamp_Press; // Plot Temp

```

```
begin
  PlotLineGraph(TempS,StrToFloat(tempData.TempX));
  PlotLineGraph(PressS,StrToFloat(tempData.PressX));
end;
```

```
procedure TForm1.TestClick(Sender: TObject);
begin
  recDataStart;
end;
```

```
procedure TForm1.Thread3dStart;
begin
  if My3d = nil then
  begin
    My3D := TMy3d.Create(False);
  end;
end;
```

```
procedure TForm1.ThreadModelStop;
begin
  if MyModel <> nil then
  begin
    MyModel.Terminate;
    MyModel.Free;
    MyModel := nil;
  end;
end;
```

```
procedure TForm1.ThreadPlotStart;
begin
  if ThreadPlot = nil then
    ThreadPlot := TMyPlot.Create(False);
end;
```

```
procedure TForm1.ThreadSqlStart;
begin
  if ThreadSQL = nil then
    ThreadSQL := TMyThreadSQL.Create(False);
end;
```

```
procedure TForm1.Timer1Timer(Sender: TObject);
var
```

```

Sl:TStringList;
Data:String;
i:Integer;
begin
Application.ProcessMessages;
RunMqtt;
Memo2.Lines.Add(','+accData.aX+', '+accData.aY+', '+accData.aZ+', '+gyroData.gyroX+', '+gyroData
.gyroY+', '+gyroData.gyroZ);
end;

```

```

procedure TForm1.TMSMQTTClient1ConnectedStatusChanged(ASender: TObject;
const AConnected: Boolean; AStatus: TTMSMQTTConnectionStatus);
begin
if AConnected then
begin
TMSMQTTClient1.Subscribe(ChatChannel);
end
else begin
case AStatus of
csConnectionRejected_InvalidProtocolVersion,
csConnectionRejected_InvalidIdentifier,
csConnectionRejected_ServerUnavailable,
csConnectionRejected_InvalidCredentials,
csConnectionRejected_ClientNotAuthorized;; // the connection is rejected by broker
csConnectionLost;; // the connection with the broker is lost
csConnecting;; // The client is trying to connect to the broker
csReconnecting;; // The client is trying to reconnect to the broker
end;
end;

end;

```

```

procedure TForm1.TMSMQTTClient1PublishReceived(ASender: TObject;
APacketID: Word; ATopic: string; APayload: TArray<System.Byte>);
var
msg,orig: string;
vp: integer;
alright: boolean;
begin
msg := TEncoding.UTF8.GetString(APayload);

vp := pos('!', msg);

if vp > 0 then

```

```

begin
  orig := copy(msg,1,vp-1);
  alright := orig <> TMSMQTTClient1.ClientID;

  msg := copy(msg, vp + 1, Length(msg));
  AddMessage(msg, alright);
end;
end;

procedure TForm1.WritelnCfg;
var
  vIni:TIniFile;
begin
  vIni:=TIniFile.Create(iniFilePath);
  try
    vIni.WriteBool(CheckBox1.ClassName, 'CheckBox1.Checked', CheckBox1.IsChecked);
  finally
    vIni.Free;
  end;
end;

procedure TForm1.StartSQLClick(Sender: TObject);
begin
  if Start.Enabled=True then
  begin
    ShowMessage('Please Enable Start');
  end
  else
  begin
    ThreadSqlStart;
    StartSQL.Enabled:=False;
    StopSQL.Enabled:=True;
  end;
end;

procedure TForm1.StopClick(Sender: TObject);
begin
  StopClient;
  EndThreadSQL;
  //EndThread3d;
  Timer1.Enabled:=False;
  Start.Enabled:=True;
  Stop.Enabled:=False;
  if CheckBox1.IsChecked then

```

```

begin
    EndThreadSQL;
end;
end;

procedure TForm1.StopClient;
begin
    if MyCleint <> nil then
    begin
        MyCleint.Terminate;
        MyCleint.Free;
        MyCleint:=nil;
    end;
end;

procedure TForm1.StopSaveClick(Sender: TObject);
begin
    recDataStop;
    StopSave.Enabled:=False;
    SaveData.Enabled:=True;
end;

procedure TForm1.StopSQLClick(Sender: TObject);
begin
    StopSQL.Enabled:=False;
    EndThreadSQL;
    StartSQL.Enabled:=true;
    SQLStat.Text:='SQL is Stop';
end;

procedure TForm1.SumPlot; // All Plot Data
begin
    PlotAccD();
    PlotGyroD();
    PlotNorm();
    PlotMag();
    PlotMagH();
    Teamp_Press();
end;

procedure TForm1.SaveDataClick(Sender: TObject);
var
    Buff:String;
    l,x:integer;

```

```

S:String;
begin
if Start.Enabled=True then
begin
  ShowMessage('Please Enable Start');
end
else
begin
recDataStart;
SaveData.Enabled:=False;
StopSave.Enabled:=True;
end;
end;

```

```

procedure TForm1.SetZero;
begin
ImuData:='0';
accData.aX:='0';
accData.aY:='0';
accData.aZ:='0';
accData.rq:='0';
gyroData.gyroX:='0';
gyroData.gyroY:='0';
gyroData.gyroZ:='0';
magData.magX:='0';
magData.magY:='0';
magData.magZ:='0';
magData.magH:='0';
tempData.TempX:='0';
tempData.PressX:='0';
Norm := '0';
lastData:='0';
MyData.accX:=0;
MyData.accY:=0;
MyData.accZ:=0;
MyData.accNorm:=0;
Mydata.gyroR:=0;
Mydata.gyroP:=0;
Mydata.gyroY:=0;
end;

```

```

procedure TForm1.ShowDataSQL;
begin

```



```
DataToSQL(StrToFloat(Form1.accData.aX),StrToFloat(Form1.accData.aY),StrToFloat(Form1.accData.aZ),StrToFloat(Form1.accData.rq),
```

```
StrToFloat(Form1.gyroData.gyroX),StrToFloat(Form1.gyroData.gyroY),StrToFloat(Form1.gyroData.gyroZ),
```

```
StrToFloat(Form1.magData.magX),StrToFloat(Form1.magData.magY),StrToFloat(Form1.magData.magZ),StrToFloat(Form1.magData.magH),  
StrToFloat(Form1.tempData.TempX),StrToFloat(Form1.tempData.PressX),StrToFloat(lastData));  
end;
```

```
procedure TForm1.StartClient;  
begin  
if MyClient = nil then  
MyClient := TClientRead.create(false);  
end;
```

```
procedure TForm1.StartClick(Sender: TObject);  
begin  
if IdTCPClient1.Connected=False then  
begin  
ShowMessage('Please Connect The Sever');  
end  
else  
begin  
Start.Enabled:=False;  
Stop.Enabled:=True;  
StartClient;  
//ThreadSqlStart;  
Timer1.Enabled:=True;  
//Thread3dStart;  
if CheckBox1.IsChecked then  
begin  
ThreadSqlStart;  
end  
else  
begin  
EndThreadSql;  
end;  
end;  
end;  
end;
```

```
procedure TForm1.startGrid;
```

```

begin

end;

procedure TForm1.AddLog(AMessage: string);
begin
    if Memo1.Lines.Count > 100 then
    begin
        Memo1.Lines.Clear;
        Application.ProcessMessages; //without this, scrollbars will show wrong size/position
    end;
    Memo1.Lines.Add(AMessage);
    Memo1.GoToTextEnd;
end;

procedure TForm1.AddMessage(AMessage: string; AlignRight: boolean);
var
    li: Tlistboxitem;
begin
    li := Tlistboxitem.Create(self);
    li.StyledSettings := li.StyledSettings - [TStyledSetting.Other];
    li.Text := AMessage;
    li.Height := 22;
    li.VertTextAlign := TTextAlign.Trailing;

    if AlignRight then
        li.TextAlign := TTextAlign.Trailing
    else
        li.TextAlign := TTextAlign.Leading;
    listbox1.AddObject(li);
end;

function TForm1.CallGyroForce(NewData: TGyro): TGyroForce;
var
    NewAngle: TImuAngle;
    NewForce: TGyroForce;
begin

    NewAngle.AngX.NewData:=GyroAng.AngX.OldData+
        (NewData.X*SAMPLING_TIME );
    //GyroAng.AngX.OldData:=NewAngle.AngX.NewData;

    NewAngle.AngY.NewData:=GyroAng.AngY.OldData+
        (NewData.Y*SAMPLING_TIME);

```

```

//GyroAng.AngY.OldData:=NewAngle.AngY.NewData;

NewAngle.AngZ.NewData:=GyroAng.AngZ.OldData+
(NewData.Z*SAMPLING_TIME );
//GyroAng.AngZ.OldData:=NewAngle.AngZ.NewData;

NewAngle.AngX.NewData:=DegToRad(NewAngle.AngX.NewData);
NewAngle.AngY.NewData:=DegToRad(NewAngle.AngY.NewData);
NewAngle.AngZ.NewData:=DegToRad(NewAngle.AngZ.NewData);

NewForce.FX:=1/
(Sqrt(1+(Cot(NewAngle.AngX.NewData)*Cot(NewAngle.AngX.NewData))*
(Sec(NewAngle.AngY.NewData)*Sec(NewAngle.AngY.NewData))));

if NewAngle.AngX.NewData<0 then
NewForce.FX:=(-1)*NewForce.FX;

NewForce.FY:=1/
Sqrt(1+(Cot(NewAngle.AngY.NewData)*Cot(NewAngle.AngY.NewData))*
((Sec(NewAngle.AngX.NewData)*Sec(NewAngle.AngX.NewData))));

if NewAngle.AngY.NewData<0 then
NewForce.FY:=(-1)*NewForce.FY;

NewForce.FZ:=Sqrt(1-(NewForce.FX*NewForce.FX)-(NewForce.FY*NewForce.FY));

Result:=NewForce;
end;

procedure TForm1.callini;
begin
iniFilePath:=ExtractFilePath(ParamStr(0)) + 'cfg.ini'; // application exe
if not FileExists(iniFilePath) then
Writeln(Cfg) // Set Object Config as Default
else
ReadIniCfg;
end;

procedure TForm1.CallMqtt;
begin
TMSMQTTClient1.BrokerHostName := 'broker.mqttdashboard.com';
TMSMQTTClient1.Connect();
memo2.Lines.Add('Connect');

```

end;

```
function TForm1.CalMovingAvg(DataIn: Integer;
  var DataBuff: TMovingAvgBuffer): Integer;
var
  i, SumIn: Integer;
begin
  SumIn:=0;
  for i := 1 to MOVIVE_AVG_LEN do
    begin
      if i<MOVIVE_AVG_LEN then
        DataBuff.Data[i]:=DataBuff.Data[i+1]  // Shift Data
      else
        DataBuff.Data[i]:=DataIn; // Last Data = Data input

        SumIn:=SumIn+DataBuff.Data[i];

      end;
    end;
  Result:=Round(SumIn/MOVIVE_AVG_LEN);
end;
```

```
procedure TForm1.CheckBox1Change(Sender: TObject);
begin
  if CheckBox1.IsChecked =true then
    begin
      StartSQL.Enabled:=False;
      StopSQL.Enabled:=False;
    end
  else
    begin
      StartSQL.Enabled:=True;
      StopSQL.Enabled:=False;
      EndThreadSQL;
    end
  end;
```

```
function TForm1.ChkNoMove(OldVal, NewVal: Integer): Boolean;
var
  AbsDiff: Integer;
begin
  AbsDiff:=abs(NewVal-OldVal);
  if AbsDiff<=1 then  // Stationary State threshold
    begin
      AccNoMoveCount:=AccNoMoveCount+1;  // Waiting for long time
```

```

if 20<AccNoMoveCount then    // wait for 20*Sampling time
begin
    AccNoMoveCount:=0;
    Result:=True;
end
else
    Result:=False;
end
else
begin
    AccNoMoveCount:=0;
    Result:=False;
end;
end;

```

```

function TForm1.ChkNoMove2(AccNorm: Single): Boolean;
var
    AbsNorm:Single;
begin
    AbsNorm:=abs(AccNorm-ACC_NORM_VAL);
    if AbsNorm<3 then    // Stationary State threshold
    begin
        AccNoMoveCount:=AccNoMoveCount+1;    // Waiting for long time
        if 20<AccNoMoveCount then    // wait for 20*Sampling time
        begin
            AccNoMoveCount:=0;
            Result:=True;
        end
        else
            Result:=False;
        end
    else
    begin
        AccNoMoveCount:=0;
        Result:=False;
    end;
end;

```

```

procedure TForm1.ConnectClick(Sender: TObject);
begin
try
    IdTCPClient1.Connect;
Except
    ShowMessage('Fail Connection');

```

```
end;  
end;
```

```
procedure TForm1.CreateCleint;  
begin  
if MyCleint = nil then  
    MyCleint := TClientRead.create(false);  
end;
```

```
procedure TForm1.DataToSQL(aX, aY, aZ, aN, gR, gP, gY, mgX, mgY, mgZ, mgH, temp,  
    press, Alti: Single);  
begin  
    Form1.FDTable1.Append;    // Insert at last  
    Form1.FDTable1DateTime.Value:=Now;  
    Form1.FDTable1accelerationX.Value:=aX;  
    Form1.FDTable1accelerationY.Value:=aY;  
    Form1.FDTable1accelerationZ.Value:=aZ;  
    Form1.FDTable1accelerationNorm.Value:=aN;  
    //  
    Form1.FDTable1GyroX.Value:=gR;  
    Form1.FDTable1GyroY.Value:=gP;  
    Form1.FDTable1GyroZ.Value:=gY;  
    //  
    Form1.FDTable1MagnetoX.Value:=mgX;  
    Form1.FDTable1MagnetoY.Value:=mgY;  
    Form1.FDTable1MagnetoZ.Value:=mgZ;  
    Form1.FDTable1magHorizDirection.Value:=mgH;  
    //  
    Form1.FDTable1Temperature.Value:=temp;  
    Form1.FDTable1Pressure.Value:=press;  
    //  
    Form1.FDTable1Altitude.Value:=Alti;  
    Form1.FDTable1.Post;  
end;
```

```
procedure TForm1.DisconnectClick(Sender: TObject);  
begin  
    IdTCPClient1.Disconnect;  
end;
```

```
procedure TForm1.EndThread3d;  
begin
```

```
if My3d <> nil then
begin
    My3d.Terminate;
    My3d.Free;
    My3d := nil;
end;
end;
```

```
procedure TForm1.EndThreadPlot;
begin
    if ThreadPlot <> nil then
    begin
        ThreadPlot.Terminate;
        ThreadPlot.Free;
        ThreadPlot := nil;
    end;
end;
```

```
procedure TForm1.EndThreadSQL;
begin
    if ThreadSQL <> nil then
    begin
        ThreadSQL.Terminate;
        ThreadSQL.Free;
        ThreadSQL:=nil;
        SQLStat.Text:='SQL is Stop';
    end;
end;
```

```
function TForm1.FloatToStr2(Data: Single): String;
begin
    Result:= Format('%0.2f', [Data]);
end;
```

```
procedure TForm1.FormClose(Sender: TObject; var Action: TCloseAction);
begin
    ThreadModelStop;
    EndThreadSQL;
    EndThreadPlot;
    recDataStop;
    EndThread3d;
    StopClient;
    Timer1.Enabled:=False;
    Application.Terminate;
```

end;

```
procedure TForm1.FormCreate(Sender: TObject);
var
  I:Integer;
begin
  IdTCPClient1.Host := Edit1.Text;
  IdTCPClient1.Port := StrToInt(Edit2.Text);
  PreModel;
  SetZero;
  ThreadPlotStart;
  callMqtt;
  Thread3dStart;
  MyDataPath:=ExtractFilePath(Application.Name)+'MyFile.txt';
  //WebBrowser1.Navigate(EditWeb.Text);
  Disconnect.Enabled:=False;
  Stop.Enabled:=False;
  StopSQL.Enabled:=False;
  StopSave.Enabled:=False;
  callini;
  reCheck;
end;
```

```
procedure TForm1.FormDestroy(Sender: TObject);
begin
  WriteIniCfg;
end;
```

```
procedure TForm1.FormKeyDown(Sender: TObject; var Key: Word; var KeyChar: Char;
  Shift: TShiftState);
begin
  if (Key = 27) and (ssShift in Shift) then
  begin
    Application.Terminate;
  end;
end;
```

end;

```
//-----cal HP-----//
function TForm1.HpFilter(k, OldVal, InputVal: Single): Single;
var
  Ans:Single;
begin
  Ans:=(k*OldVal)+((1-k)*InputVal);
```



```
Result:=Ans;  
end;
```

```
procedure TForm1.IdTCPClient1Connected(Sender: TObject);  
begin  
Connect.Enabled:=False;  
Disconnect.Enabled:=True;  
end;
```

```
procedure TForm1.IdTCPClient1Disconnected(Sender: TObject);  
begin  
Connect.Enabled:=True;  
Disconnect.Enabled:=False;  
end;
```

```
procedure TForm1.IdTCPClient1Status(ASender: TObject; const AStatus: TIdStatus;  
const AStatusText: string);  
begin  
  
end;
```

```
//-----cal LP-----//  
function TForm1.LpFilter(k, OldVal, InputVal: Single): Single;  
var  
Ans:Single;  
begin  
Ans:=(k*InputVal)+((1-k)*OldVal);  
Result:=Ans;  
end;
```

```
procedure TForm1.PlotAcc; //Plot Acc  
begin  
PlotLineGraph(AccX, StrToFloat(accData.aX));  
PlotLineGraph(AccY, StrToFloat(accData.aY));  
PlotLineGraph(AccZ, StrToFloat(accData.aZ));  
end;
```

```
procedure TForm1.PlotAccD; //Plot Acc  
begin  
PlotLineGraph(AccXD, StrToFloat(accData.aX));  
PlotLineGraph(AccYD, StrToFloat(accData.aY));  
PlotLineGraph(AccZD, StrToFloat(accData.aZ));
```

end;

procedure TForm1.PlotGyro; //Plot Gyro

begin

PlotLineGraph(GyroX, StrToFloat(gyroData.gyroX));

PlotLineGraph(GyroY, StrToFloat(gyroData.gyroY));

PlotLineGraph(GyroZ, StrToFloat(gyroData.gyroZ));

end;

procedure TForm1.PlotGyroD; //Plot Gyro

begin

PlotLineGraph(GyroXD, StrToFloat(gyroData.gyroX));

PlotLineGraph(GyroYD, StrToFloat(gyroData.gyroY));

PlotLineGraph(GyroZD, StrToFloat(gyroData.gyroZ));

end;

procedure TForm1.PlotLineGraph(Graph: TLineSeries; Data: Real);

var

tmpX:Double;

begin

with Graph do

begin

if XValues.Count<100 then

begin

Add(Data);

end

else

begin

tmpX:=XValues[1]-XValues[0];

Delete(0);

AddXY(XValues.Last+tmpX, Data,"",clTeeColor);

end;

end;

end;

procedure TForm1.PlotMag; // Plot Mag

begin

PlotLineGraph(MagX, StrToFloat(magData.magX));

PlotLineGraph(MagY, StrToFloat(magData.magY));

PlotLineGraph(MagZ, StrToFloat(magData.magZ));

end;

procedure TForm1.PlotMagH; // Plot MagH

begin

```
PlotLineGraph(MagH, StrToFloat(magData.magH));  
end;
```

```
procedure TForm1.PlotNorm; // Plot AccSQRT  
begin  
PlotLineGraph(AccSQRTD, StrToFloat(accData.rq));  
end;
```

```
procedure TForm1.PreModel;  
begin  
if MyModel = nil then  
    MyModel := TModel.Create(False);  
end;
```

```
procedure TForm1.ReadIniCfg;  
var  
    vIni:TIniFile;  
begin  
    vIni:=TIniFile.Create(iniFilePath);  
    try  
        CheckBox1.IsChecked:=vIni.ReadBool(CheckBox1.ClassName, 'CheckBox1.Checked', False);  
    finally  
        vIni.Free;  
    end;  
end;
```

```
procedure TForm1.recDataStart;  
begin  
if MyRec = nil then  
    MyRec := TrecData.Create(False);  
end;
```

```
procedure TForm1.recDataStop;  
begin  
if MyRec <> nil then  
begin  
    Myrec.Free;  
    Myrec.Terminate;  
    Myrec := nil;  
end;  
end;
```

```
procedure TForm1.reCheck;  
begin
```

```

if CheckBox1.IsChecked then
begin
    StartSQL.Enabled:=False;
    StopSQL.Enabled:=False;
    ShowMessage('Start With SQL');
end
else
begin
    StartSQL.Enabled:=True;
    StopSQL.Enabled:=False;
end;
end;

```

```

procedure TForm1.recMyData;
var
i:Integer;
begin
    for i := 1 to 100 do
        begin
            // sleep(100);
            MyImu[i].accX:=StrToFloat(accData.aX);
            MyImu[i].accY:=StrToFloat(accData.aY);
            MyImu[i].accZ:=StrToFloat(accData.aZ);
            MyImu[i].accNorm:=StrToFloat(accData.rq);
            MyImu[i].gyroR:=StrToFloat(gyroData.gyroX);
            MyImu[i].gyroP:=StrToFloat(gyroData.gyroY);
            MyImu[i].gyroY:=StrToFloat(gyroData.gyroZ);
            MyImu[i].magX:=StrToFloat(magData.magX);
            MyImu[i].magY:=StrToFloat(magData.magY);
            MyImu[i].magZ:=StrToFloat(magData.magZ);
        end;
    end;
end;

```

```

procedure TForm1.ReFreshClick(Sender: TObject);
begin
TMSFMXWebBrowser1.Navigate(EditWeb.Text);
end;

```

```

procedure TForm1.RunMqtt;
begin
    TMSMQTTClient1.Publish(ChatChannel, TMSMQTTClient1.ClientID+'!' + memo2.Lines.Text);
    memo2.Lines.Clear;
end;

```

```
{ TClientRead }
```

```
procedure TClientRead.Execute;
var
  Sl:TStringList;
  Data:String;
begin
  inherited;
  try
    repeat
      Application.ProcessMessages;
      Form1.IdTCPClient1.Socket.WriteLn('b'+#13#10);
      Form1.Edit3.Text:=Form1.IdTCPClient1.Socket.ReadLn;
      Form1.AddLog(Form1.Edit3.text);
      Sl:=TStringList.Create;
      Sl.CommaText:=Form1.Edit3.Text; //Extrax string
      if Sl.Count = 14 then
        begin
          Form1.accData.aX:=Sl[0];
          Form1.accData.aY:=Sl[1];
          Form1.accData.aZ:=Sl[2];
          Form1.accData.rq:=Sl[3];
          Form1.gyroData.gyroX:=Sl[4];
          Form1.gyroData.gyroY:=Sl[5];
          Form1.gyroData.gyroZ:=Sl[6];
          Form1.magData.magX:=Sl[7];
          Form1.magData.magY:=Sl[8];
          Form1.magData.magZ:=Sl[9];
          Form1.magData.magH:=Sl[10];
          Form1.tempData.TempX:=Sl[11];
          Form1.tempData.PressX:=Sl[12];
          lastData:=Sl[13];
        end;
      if Assigned(Sl) then
        FreeAndNil(Sl);
      Form1.recMyData;
    until Terminated;
  except
    ShowMessage('Please Connecte The Sever!');
  end;
end;
```

```
{ TModel }
```

```

procedure TModel.Execute;
begin
    inherited;
    repeat
        Application.ProcessMessages;
        Form1.PlotAcc();
        Form1.PlotGyro();
        Sleep(100);
    until Terminated;
end;

```

```

{ TMyThreadSQL }

```

```

procedure TMyThreadSQL.DataToSQL(aX, aY, aZ, aN, gR, gP, gY, mgX, mgY, mgZ, mgH,
    temp, press, Alti: Single);
begin
    Form1.FDTable1.Append;    // Insert at last
    Form1.FDTable1DateTime.Value:=Now;
    Form1.FDTable1accelerationX.Value:=aX;
    Form1.FDTable1accelerationY.Value:=aY;
    Form1.FDTable1accelerationZ.Value:=aZ;
    Form1.FDTable1accelerationNorm.Value:=aN;
    //
    Form1.FDTable1GyroX.Value:=gR;
    Form1.FDTable1GyroY.Value:=gP;
    Form1.FDTable1GyroZ.Value:=gY;
    //
    Form1.FDTable1MagnetoX.Value:=mgX;
    Form1.FDTable1MagnetoY.Value:=mgY;
    Form1.FDTable1MagnetoZ.Value:=mgZ;
    Form1.FDTable1magHorizDirection.Value:=mgH;
    //
    Form1.FDTable1Temperature.Value:=temp;
    Form1.FDTable1Pressure.Value:=press;
    //
    Form1.FDTable1Altitude.Value:=Alti;
    Form1.FDTable1.Post;
end;

```

```

procedure TMyThreadSQL.Execute;
begin
    inherited;
    inherited;

```

```

Form1.SQLStat.Text:='SQL is Start';
lastData:='0';
repeat
Application.ProcessMessages;
Synchronize>ShowDataSQL;
Sleep(5000);
until Terminated;
end;

procedure TMyThreadSQL.ShowDataSQL;
begin

DataToSQL(StrToFloat(Form1.accData.aX),StrToFloat(Form1.accData.aY),StrToFloat(Form1.accData.aZ),StrToFloat(Form1.accData.rq),

StrToFloat(Form1.gyroData.gyroX),StrToFloat(Form1.gyroData.gyroY),StrToFloat(Form1.gyroData.gyroZ),

StrToFloat(Form1.magData.magX),StrToFloat(Form1.magData.magY),StrToFloat(Form1.magData.magZ),StrToFloat(Form1.magData.magH),
StrToFloat(Form1.tempData.TempX),StrToFloat(Form1.tempData.PressX),StrToFloat(lastData));
end;

{ TMyPlot }

procedure TMyPlot.Execute;
begin
inherited;
repeat
Application.ProcessMessages;
Sleep(100);
Synchronize(Form1.SumPlot);
until Terminated;
end;

{ TrecData }

procedure TrecData.Execute;
var
Buff:String;
l,x:integer;
begin
inherited;
i:=0;

```

```

AssignFile(Form1.MyDataFile,'RecordIMU\'+'+FormatDateTime('hh_nn_ss',
Now)+Form1.MyDataPath); {Assigns the Filename}
Rewrite(Form1.MyDataFile); {Create a new file }
Buff:='No, Time, AccX, AccY, AccZ, AccNorm, GyroY, GyroZ';
WriteLn(Form1.MyDataFile, Buff);
repeat
    Application.ProcessMessages;
    Inc(i);
    Sleep(100);
    Form1.MyData.accX:=StrToFloat(Form1.accData.aX);
    Form1.MyData.accY:=StrToFloat(Form1.accData.aY);
    Form1.MyData.accZ:=StrToFloat(Form1.accData.aZ);
    Form1.MyData.accNorm:=StrToFloat(Form1.accData.rq);
    Form1.MyData.gyroR:=StrToFloat(Form1.gyroData.gyroX);
    Form1.MyData.gyroP:=StrToFloat(Form1.gyroData.gyroY);
    Form1.MyData.gyroY:=StrToFloat(Form1.gyroData.gyroZ);
//
Form1.Memo3.Lines.Add(FloatToStr(Form1.MyData.accX)+' '+FloatToStr(Form1.MyData.accY)+'
'+FloatToStr(Form1.MyData.accZ));
    Buff := IntToStr(i)+' '+FormatDateTime('dd-mm-yyyy hh:nn:ss',
Now)+' '+Form1.FloatToStr2(Form1.MyImu[i].accX)+' '+Form1.FloatToStr2(Form1.MyImu[i].acc
Y)+' '+Form1.FloatToStr2(Form1.MyImu[i].accy)+' '+Form1.FloatToStr2(Form1.MyImu[i].accNor
m)

'+Form1.FloatToStr2(Form1.MyImu[i].gyroR)+' '+Form1.FloatToStr2(Form1.MyImu[i].gyroP)+'
'+Form1.FloatToStr2(Form1.MyImu[i].gyroY);
    WriteLn(Form1.MyDataFile, Buff);
until Terminated;
Closefile(Form1.MyDataFile); {Closes file } //save
end;

```

{ Tmy2d }

```

procedure Tmy3d.callSig;
var
    Sl:TStringList;
    Data:String;
    i:Integer;
begin
    Application.ProcessMessages;
    Form1.Model3D1.Position.X := StrToFloat(Form1.accData.aX);
    Form1.Model3D1.Position.Y := StrToFloat(Form1.accData.aY);
    Form1.Model3D1.Position.Z := StrToFloat(Form1.accData.aZ);
    Form1.Model3D1.RotationAngle.X := StrToFloat(Form1.gyroData.gyroX);

```



```
Form1.Model3D1.RotationAngle.Y := StrToFloat(Form1.gyroData.gyroY);  
Form1.Model3D1.RotationAngle.Z := StrToFloat(Form1.gyroData.gyroZ);  
end;
```

```
procedure Tmy3d.Execute;  
begin  
    inherited;  
    repeat  
        Application.ProcessMessages;  
        Sleep(100);  
        Synchronize(callSig);  
    until Terminated;  
end;  
  
end.
```

10. โปรแกรม Arduino

```
#include "SPI.h"  
#include "Ethernet.h"  
  
/*  
    by MohammedDamirchi  
    Home  
*/  
#include <MPU9250_asukiaaa.h>  
#include <Adafruit_BMP280.h>  
//#include <Wire.h>  
//#include <SPI.h>  
  
byte mac[] = {0xDE, 0xAD, 0xBE, 0xEF, 0xFE, 0xED};  
EthernetServer server(80);  
  
int v;  
float voltage;
```

```

int trigPin = 2; //Assign D2 as trigPin
int echoPin = 4; //Assign D4 as echoPin
long duration;
float distance;

Adafruit_BMP280 bme; // I2C
MPU9250_asukiaaa mySensor;
float aX, aY, aZ, aSqrt, gX, gY, gZ, mDirection, mX, mY, mZ;

void setup() {
  // pinMode(trigPin, OUTPUT);
  // pinMode(echoPin, INPUT);
  Serial.begin(115200); //Set Serial Communication
  Ethernet.begin(mac); //
  server.begin(); //Start Arduino as Server role
  Serial.print("Arduino as Server Role IPAddress: "); Serial.println(Ethernet.localIP());

  // Serial.begin(115200);
  while (!Serial);

#ifdef _ESP32_HAL_I2C_H_ // For ESP32
  Wire.begin(SDA_PIN, SCL_PIN);
  mySensor.setWire(&Wire);
#else
  Wire.begin();
  mySensor.setWire(&Wire);
#endif

  bme.begin();

```

```

mySensor.beginAccel();
mySensor.beginGyro();
mySensor.beginMag();

// You can set your own offset for mag values
// mySensor.magXOffset = -50;
// mySensor.magYOffset = -55;
// mySensor.magZOffset = -10;
}

void loop() {
  EthernetClient client = server.available(); //Wait connection from TCP/IP
  if (client) {
    Serial.println("Hi...New Client");
    while (client.connected()) {
      while (client.available()) {
        char data = client.read();
        Serial.println(data);
        switch (data) {
          case 'a':          // data='a'--> Do nothing
            Serial.print("");
            client.println(""); //Arduino as Server send data to LabVIEW as Client
            break;
          case 'b':          // data='b' Read voltage from A0 and send back to LabVIEW
            if (mySensor.accelUpdate() == 0) {
              aX = mySensor.accelX();
              aY = mySensor.accelY();
              aZ = mySensor.accelZ();
              aSqrt = mySensor.accelSqrt();
              Serial.print(String(aX)); Serial.print(",");

```

```

Serial.print(String(aY)); Serial.print(",");
Serial.print(String(aZ)); Serial.print(",");
Serial.print(String(aSqrt)); Serial.print(",");
//-----//
client.print(String(aX)); client.print(",");
client.print(String(aY)); client.print(",");
client.print(String(aZ)); client.print(",");
client.print(String(aSqrt)); client.print(",");
}

```

```

if (mySensor.gyroUpdate() == 0) {
  gX = mySensor.gyroX();
  gY = mySensor.gyroY();
  gZ = mySensor.gyroZ();
  client.print(String(gX)); client.print(",");
  client.print(String(gY)); client.print(",");
  client.print(String(gZ)); client.print(",");
  //-----//
  Serial.print(String(gX)); Serial.print(",");
  Serial.print(String(gY)); Serial.print(",");
  Serial.print(String(gZ)); Serial.print(",");
}

```

```

if (mySensor.magUpdate() == 0) {
  mX = mySensor.magX();
  mY = mySensor.magY();
  mZ = mySensor.magZ();
  mDirection = mySensor.magHorizDirection();
  Serial.print(String(mX)); Serial.print(",");
  Serial.print(String(mY)); Serial.print(",");

```

```

    Serial.print(String(mZ)); Serial.print(",");
    Serial.print(String(mDirection)); Serial.print(",");
    //-----//
    client.print(String(mX)); client.print(",");
    client.print(String(mY)); client.print(",");
    client.print(String(mZ)); client.print(",");
    client.print(String(mDirection)); client.print(",");
}

// Serial.print("\tTemperature(*C): ");
Serial.print(bme.readTemperature()); Serial.print(",");
//-----//
client.print(bme.readTemperature()); client.print(",");

// Serial.print("\tPressure(Inches(Hg)): ");
Serial.print(bme.readPressure() / 3377); Serial.print(",");
//-----//
client.print(bme.readPressure() / 3377); client.print(",");

// Serial.print("\tApproxAltitude(m): ");
Serial.print(bme.readAltitude(1013.25)); // this should be adjusted to your local forcase
//-----//
client.print(bme.readAltitude(1013.25)); // this should be adjusted to your local forcase

Serial.println(""); // Add an empty line
//-----//
client.println("");
break;
}


```

```


    }
  }
}
}

```

12. Dashboard Node-RED



13 Flow Program Node-RED



14. โปรแกรม Node-RED Json

```
[
  {
    "id": "3f59ad1f848847bf",
    "type": "mqtt in",
    "z": "93d7d386ad906e5f",
    "name": "Node-Sub",
    "topic": "sensor1",
    "qos": "0",
    "datatype": "auto-detect",
    "broker": "b6494bf324dc4470",
    "nl": false,
    "rap": true,
    "rh": 0,
    "inputs": 0,
    "x": 240,
    "y": 260,
    "wires": [
      [
        "05253856ddb7d8ac",
        "582e7228efeec111"
      ]
    ]
  },
  {
    "id": "05253856ddb7d8ac",
    "type": "split",
    "z": "93d7d386ad906e5f",
    "name": "",
    "spl": ", ",
    "splType": "str",
    "arraySpl": "1",
    "arraySplType": "len",
    "stream": false,
    "addname": "topic",
```

```
"x": 490,
"y": 200,
"wires": [
  []
],
{
  "id": "582e7228efeec111",
  "type": "function",
  "z": "93d7d386ad906e5f",
  "name": "Extrax1",
  "func": "var outputMsgs = [];\nvar words = msg.payload.split(\"\\n\");\nfor (var w in words) {\n//\noutputMsgs.push({ payload: words[w] });\n}\nvar text = { payload: words[0] }; \nvar accx = { payload: words[1] }; \nvar\naccy = { payload: words[2] }; \nvar accz = { payload: words[3] }; \nvar gyrox = { payload: words[4] }; \nvar gyroy = {\npayload: words[5] }; \nvar gyroz = { payload: words[6] }; \n//\nvar out7 = { payload: words[7] }; \nreturn [accx, accy, accz,\ngyrox, gyroy, gyroz];",
  "outputs": 6,
  "noerr": 0,
  "initialize": "",
  "finalize": "",
  "libs": [],
  "x": 560,
  "y": 360,
  "wires": [
    [
      "dc8c1a544e5d054c",
      "11dbd3299518a2dc",
      "db28527f1995ea3d"
    ],
    [
      "701e22f6b6d89691",
      "12947342af2887e5",
      "3b88359673e778be"
    ],
    [
      "4d2a63447a04406b",
      "6a700b94e4945a6c",

```



```
        "8358be5c055d2cd5"
    ],
    [
        "03770943bf5b0886",
        "99442b9bb65d3d21",
        "16a87ab2cafbf5db"
    ],
    [
        "f4582acc9fcdf523",
        "7804686d71a76c1d",
        "0f7a39d3204d89b3"
    ],
    [
        "549c883b57d8e198",
        "ea62f7ded1aaded9",
        "c3ce7391b9cca130"
    ]
]
},
{
    "id": "dc8c1a544e5d054c",
    "type": "debug",
    "z": "93d7d386ad906e5f",
    "name": "AccX",
    "active": true,
    "tosidebar": true,
    "console": false,
    "tostatus": false,
    "complete": "payload",
    "targetType": "msg",
    "statusVal": "",
    "statusType": "auto",
    "x": 790,
    "y": 240,
    "wires": []
},
{
```

```
    "id": "701e22f6b6d89691",
    "type": "debug",
    "z": "93d7d386ad906e5f",
    "name": "AccY",
    "active": true,
    "tosidebar": true,
    "console": false,
    "tostatus": false,
    "complete": "payload",
    "targetType": "msg",
    "statusVal": "",
    "statusType": "auto",
    "x": 790,
    "y": 280,
    "wires": []
  },
  {
    "id": "4d2a63447a04406b",
    "type": "debug",
    "z": "93d7d386ad906e5f",
    "name": "AccZ",
    "active": true,
    "tosidebar": true,
    "console": false,
    "tostatus": false,
    "complete": "payload",
    "targetType": "msg",
    "statusVal": "",
    "statusType": "auto",
    "x": 790,
    "y": 320,
    "wires": []
  },
  {
    "id": "03770943bf5b0886",
    "type": "debug",
    "z": "93d7d386ad906e5f",
```

```
"name": "GyroX",
"active": true,
"tosidebar": true,
"console": false,
"tostatus": false,
"complete": "payload",
"targetType": "msg",
"statusVal": "",
"statusType": "auto",
"x": 790,
"y": 360,
"wires": []
},
{
  "id": "f4582acc9fcd523",
  "type": "debug",
  "z": "93d7d386ad906e5f",
  "name": "GyroY",
  "active": true,
  "tosidebar": true,
  "console": false,
  "tostatus": false,
  "complete": "payload",
  "targetType": "msg",
  "statusVal": "",
  "statusType": "auto",
  "x": 790,
  "y": 400,
  "wires": []
},
{
  "id": "549c883b57d8e198",
  "type": "debug",
  "z": "93d7d386ad906e5f",
  "name": "GyroZ",
  "active": true,
  "tosidebar": true,
```

```
"console": false,
"toaststatus": false,
"complete": "payload",
"targetType": "msg",
"statusVal": "",
"statusType": "auto",
"x": 790,
"y": 440,
"wires": []
},
{
  "id": "ce85ab19d67a4932",
  "type": "inject",
  "z": "93d7d386ad906e5f",
  "name": "test",
  "props": [
    {
      "p": "payload"
    },
    {
      "p": "topic",
      "vt": "str"
    }
  ],
  "repeat": "",
  "crontab": "",
  "once": false,
  "onceDelay": 0.1,
  "topic": "",
  "payload": "0,1,2,3,4,5,6",
  "payloadType": "str",
  "x": 250,
  "y": 420,
  "wires": [
    [
      "582e7228efeec111"
    ]
  ]
}
```

```
]
},
{
  "id": "11dbd3299518a2dc",
  "type": "ui_gauge",
  "z": "93d7d386ad906e5f",
  "name": "",
  "group": "762a9c64e9042f0e",
  "order": 1,
  "width": 0,
  "height": 0,
  "gtype": "gage",
  "title": "AccX",
  "label": "units",
  "format": "{{value}}",
  "min": "-3",
  "max": "3",
  "colors": [
    "#00b500",
    "#e6e600",
    "#ca3838"
  ],
  "seg1": "",
  "seg2": "",
  "className": "",
  "x": 970,
  "y": 120,
  "wires": []
},
{
  "id": "12947342af2887e5",
  "type": "ui_gauge",
  "z": "93d7d386ad906e5f",
  "name": "",
  "group": "d45b44600d92c5d7",
  "order": 2,
  "width": 0,
```

```
"height": 0,
"ctype": "gauge",
"title": "AccY",
"label": "units",
"format": "{{value}}",
"min": "-3",
"max": "3",
"colors": [
    "#00b500",
    "#e6e600",
    "#ca3838"
],
"seg1": "",
"seg2": "",
"className": "",
"x": 970,
"y": 160,
"wires": []
},
{
    "id": "6a700b94e4945a6c",
    "type": "ui_gauge",
    "z": "93d7d386ad906e5f",
    "name": "",
    "group": "18af62378bfc9340",
    "order": 3,
    "width": 0,
    "height": 0,
    "ctype": "gauge",
    "title": "AccZ",
    "label": "units",
    "format": "{{value}}",
    "min": "-3",
    "max": "3",
    "colors": [
        "#00b500",
        "#e6e600",
```

```
        "#ca3838"
    ],
    "seg1": "",
    "seg2": "",
    "className": "",
    "x": 970,
    "y": 200,
    "wires": []
},
{
    "id": "99442b9bb65d3d21",
    "type": "ui_gauge",
    "z": "93d7d386ad906e5f",
    "name": "",
    "group": "3f7ab6be951f07ef",
    "order": 4,
    "width": 0,
    "height": 0,
    "gtype": "gage",
    "title": "GyroX",
    "label": "units",
    "format": "{{value}}",
    "min": "-500",
    "max": "500",
    "colors": [
        "#00b500",
        "#e6e600",
        "#ca3838"
    ],
    "seg1": "",
    "seg2": "",
    "className": "",
    "x": 970,
    "y": 240,
    "wires": []
},
{
```

```
"id": "7804686d71a76c1d",
"type": "ui_gauge",
"z": "93d7d386ad906e5f",
"name": "",
"group": "67da9534adb32455",
"order": 5,
"width": 0,
"height": 0,
"ctype": "gage",
"title": "GyroY",
"label": "units",
"format": "{{value}}",
"min": "-500",
"max": "500",
"colors": [
    "#00b500",
    "#e6e600",
    "#ca3838"
],
"seg1": "",
"seg2": "",
"className": "",
"x": 970,
"y": 280,
"wires": []
},
{
    "id": "ea62f7ded1aaded9",
    "type": "ui_gauge",
    "z": "93d7d386ad906e5f",
    "name": "",
    "group": "78825f875df1d4cd",
    "order": 6,
    "width": 0,
    "height": 0,
    "ctype": "gage",
    "title": "GyroZ",
```



```
"label": "units",
"format": "{{value}}",
"min": "-500",
"max": "500",
"colors": [
    "#00b500",
    "#e6e600",
    "#ca3838"
],
"seg1": "",
"seg2": "",
"className": "",
"x": 970,
"y": 320,
"wires": []
},
{
    "id": "db28527f1995ea3d",
    "type": "ui_chart",
    "z": "93d7d386ad906e5f",
    "name": "",
    "group": "762a9c64e9042f0e",
    "order": 7,
    "width": 0,
    "height": 0,
    "label": "AccX",
    "chartType": "line",
    "legend": "false",
    "xformat": "HH:mm:ss",
    "interpolate": "linear",
    "nodata": "",
    "dot": false,
    "ymin": "-3",
    "ymax": "3",
    "removeOlder": 1,
    "removeOlderPoints": "1000",
    "removeOlderUnit": "60",
```

```
"cutout": 0,
"useOneColor": false,
"useUTC": true,
"colors": [
    "#1f77b4",
    "#aec7e8",
    "#ff7f0e",
    "#2ca02c",
    "#98df8a",
    "#d62728",
    "#ff9896",
    "#9467bd",
    "#c5b0d5"
],
"outputs": 1,
"useDifferentColor": false,
"className": "",
"x": 970,
"y": 380,
"wires": [
    []
]
},
{
    "id": "3b88359673e778be",
    "type": "ui_chart",
    "z": "93d7d386ad906e5f",
    "name": "",
    "group": "d45b44600d92c5d7",
    "order": 8,
    "width": 0,
    "height": 0,
    "label": "AccY",
    "chartType": "line",
    "legend": "false",
    "xformat": "HH:mm:ss",
    "interpolate": "linear",
```

```
"nodata": "",
"dot": false,
"ymin": "-3",
"ymax": "3",
"removeOlder": 1,
"removeOlderPoints": "1000",
"removeOlderUnit": "60",
"cutout": 0,
"useOneColor": false,
"useUTC": true,
"colors": [
    "#1f77b4",
    "#aec7e8",
    "#ff7f0e",
    "#2ca02c",
    "#98df8a",
    "#d62728",
    "#ff9896",
    "#9467bd",
    "#c5b0d5"
],
"outputs": 1,
"useDifferentColor": false,
"className": "",
"x": 970,
"y": 420,
"wires": [
    []
]
},
{
    "id": "8358be5c055d2cd5",
    "type": "ui_chart",
    "z": "93d7d386ad906e5f",
    "name": "",
    "group": "18af62378bfc9340",
    "order": 9,
```

```
"width": 0,
"height": 0,
"label": "AccZ",
"chartType": "line",
"legend": "false",
"xformat": "HH:mm:ss",
"interpolate": "linear",
"nodata": "",
"dot": false,
"ymin": "-3",
"ymax": "3",
"removeOlder": 1,
"removeOlderPoints": "1000",
"removeOlderUnit": "60",
"cutout": 0,
"useOneColor": false,
"useUTC": true,
"colors": [
    "#1f77b4",
    "#aec7e8",
    "#ff7f0e",
    "#2ca02c",
    "#98df8a",
    "#d62728",
    "#ff9896",
    "#9467bd",
    "#c5b0d5"
],
"outputs": 1,
"useDifferentColor": false,
"className": "",
"x": 970,
"y": 460,
"wires": [
    []
]
},
```

```
{
  "id": "16a87ab2cafbf5db",
  "type": "ui_chart",
  "z": "93d7d386ad906e5f",
  "name": "",
  "group": "3f7ab6be951f07ef",
  "order": 10,
  "width": 0,
  "height": 0,
  "label": "GyroX",
  "chartType": "line",
  "legend": "false",
  "xformat": "HH:mm:ss",
  "interpolate": "linear",
  "nodata": "",
  "dot": false,
  "ymin": "-500",
  "ymax": "500",
  "removeOlder": 1,
  "removeOlderPoints": "1000",
  "removeOlderUnit": "60",
  "cutout": 0,
  "useOneColor": false,
  "useUTC": true,
  "colors": [
    "#1f77b4",
    "#aec7e8",
    "#ff7f0e",
    "#2ca02c",
    "#98df8a",
    "#d62728",
    "#ff9896",
    "#9467bd",
    "#c5b0d5"
  ],
  "outputs": 1,
  "useDifferentColor": false,
```

```
"className": "",
"x": 970,
"y": 500,
"wires": [
  []
],
},
{
  "id": "0f7a39d3204d89b3",
  "type": "ui_chart",
  "z": "93d7d386ad906e5f",
  "name": "",
  "group": "67da9534adb32455",
  "order": 11,
  "width": 0,
  "height": 0,
  "label": "GyroY",
  "chartType": "line",
  "legend": "false",
  "xformat": "HH:mm:ss",
  "interpolate": "linear",
  "nodata": "",
  "dot": false,
  "ymin": "-500",
  "ymax": "500",
  "removeOlder": 1,
  "removeOlderPoints": "1000",
  "removeOlderUnit": "60",
  "cutout": 0,
  "useOneColor": false,
  "useUTC": true,
  "colors": [
    "#1f77b4",
    "#aec7e8",
    "#ff7f0e",
    "#2ca02c",
    "#98df8a",
```

```
        "#d62728",
        "#ff9896",
        "#9467bd",
        "#c5b0d5"
    ],
    "outputs": 1,
    "useDifferentColor": false,
    "className": "",
    "x": 970,
    "y": 540,
    "wires": [
        []
    ]
},
{
    "id": "c3ce7391b9cca130",
    "type": "ui_chart",
    "z": "93d7d386ad906e5f",
    "name": "",
    "group": "78825f875df1d4cd",
    "order": 12,
    "width": 0,
    "height": 0,
    "label": "GyroZ",
    "chartType": "line",
    "legend": "false",
    "xformat": "HH:mm:ss",
    "interpolate": "linear",
    "nodata": "",
    "dot": false,
    "ymin": "-500",
    "ymax": "500",
    "removeOlder": 1,
    "removeOlderPoints": "1000",
    "removeOlderUnit": "60",
    "cutout": 0,
    "useOneColor": false,
```

```
"useUTC": true,
"colors": [
  "#1f77b4",
  "#aec7e8",
  "#ff7f0e",
  "#2ca02c",
  "#98df8a",
  "#d62728",
  "#ff9896",
  "#9467bd",
  "#c5b0d5"
],
"outputs": 1,
"useDifferentColor": false,
"className": "",
"x": 970,
"y": 580,
"wires": [
  []
]
},
{
  "id": "b6494bf324dc4470",
  "type": "mqtt-broker",
  "name": "hiveMqtt-pub",
  "broker": "broker.mqttdashboard.com",
  "port": "1883",
  "clientid": "",
  "autoConnect": true,
  "usetls": false,
  "protocolVersion": "4",
  "keepalive": "60",
  "cleansession": true,
  "birthTopic": "",
  "birthQos": "0",
  "birthPayload": "",
  "birthMsg": {}
```



```
"closeTopic": "",
"closeQos": "0",
"closePayload": "",
"closeMsg": {},
"willTopic": "",
"willQos": "0",
"willPayload": "",
"willMsg": {},
"userProps": "",
"sessionExpiry": ""
},
{
  "id": "762a9c64e9042f0e",
  "type": "ui_group",
  "name": "AccelerationX",
  "tab": "4b11d5cd7d4d9975",
  "order": 2,
  "disp": true,
  "width": "6",
  "collapse": false,
  "className": ""
},
{
  "id": "d45b44600d92c5d7",
  "type": "ui_group",
  "name": "accelerationY",
  "tab": "4b11d5cd7d4d9975",
  "order": 3,
  "disp": true,
  "width": "6",
  "collapse": false,
  "className": ""
},
{
  "id": "18af62378bfc9340",
  "type": "ui_group",
  "name": "accelerationZ",
```

```
"tab": "4b11d5cd7d4d9975",
"order": 4,
"disp": true,
"width": "6",
"collapse": false,
"className": ""
},
{
  "id": "3f7ab6be951f07ef",
  "type": "ui_group",
  "name": "GyroScopeX",
  "tab": "4b11d5cd7d4d9975",
  "order": 5,
  "disp": true,
  "width": "6",
  "collapse": false,
  "className": ""
},
{
  "id": "67da9534adb32455",
  "type": "ui_group",
  "name": "GyroScopeY",
  "tab": "4b11d5cd7d4d9975",
  "order": 6,
  "disp": true,
  "width": "6",
  "collapse": false,
  "className": ""
},
{
  "id": "78825f875df1d4cd",
  "type": "ui_group",
  "name": "GyroScopeZ",
  "tab": "4b11d5cd7d4d9975",
  "order": 7,
  "disp": true,
  "width": "6",
```

```
    "collapse": false,  
    "className": ""  
  },  
  {  
    "id": "4b11d5cd7d4d9975",  
    "type": "ui_tab",  
    "name": "IMU",  
    "icon": "dashboard",  
    "disabled": false,  
    "hidden": false  
  }  
]
```